



0971 / 103

Vermont Castings, Majestic Products reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

## Encore Multi-Fuel Heater

### Model 2547

Item Description	Part Number
1. Secondary Air Cover Plate	1601771
2. Flue Collar (8")	See Chart Pg. 40
3. Back	See Chart Pg. 40
4. Left Griddle Quad	1301807
5. Right Griddle Quad	1301832

Item Description	Part Number
6. Griddle	1300797
7. Griddle Handle Assembly	5004022
8. Top	See Chart Pg. 40
9. Wedge (2)	1301810
10. Upper Fireback <sup>1</sup>	1308639

## Encore Multi-Fuel Heater

### Model 2547 (continued)

Item Description	Part Number
11. Flue Deflector	1409083
12. Damper <sup>1</sup>	1308631
13. Damper Tabs (2) <sup>1</sup>	1601488
14. Damper Rod	1600851
15. Combustion Throat Hood	1301145
16. Lower Fireback	1308627
17. Damper Handle Screw	1201294
18. Damper Handle	1600620
19. Handle Insert	1600650
20. Steel Handle Stub	1600608
21. Left Side	See Chart Pg. 40
22. Left Air Plate (Inner Side)	1308621
23. Left Firebrick	1601885
24. Right Air Plate (Inner Side)	1308622
25. Right Side	See Chart Pg. 40
26. Right Firebrick	1601884
27. Thermostat Handle Assembly	3000276 5004264 STUB
28. Thermostat Assembly	5005470
29. Bottom Grate	1307434
30. Front Grate	1308640
31. Primary Air Tube Cover Plate	1308609
32. Primary Air Frame	1307411
33. Primary Air Regulatory System	5000337
34. Bottom	1308638
35. Ashlip	See Chart Pg. 40
36. Leg	See Chart Pg. 40
37. Leg Leveler	1201745

Item Description	Part Number
38. Ashdrop	1308603
39. Ashdoor Latch Pawl	1300515
40. Ashdoor	1308607
41. Ashdoor Handle (wood)	1600663
42. Ashdoor Hinge Pin	1208608
43. Cotter Pin, Ashdoor	30001749
44. Ashdoor Hinge Support	1308605
45. Ashpan	1601025
46. Ashpan Bracket	1601039
47. Ashpan Cover	1601027
48. Airwash Manifold	1308615
49. Front	See Chart Pg. 40
50. Left Door Air Manifold	1307403
51. Left Door	See Chart Pg. 40
52. Door Hinge Strip	1308634
53. Right Door Air Manifold	1307404
54. Door Handle Assy w/Set Screw	30001759
55. Right Door	See Chart Pg. 40
56. Door Gasket	1203588
57. Gasket, Fiberglass 3/16"	1203556
58. Left Door Glass <sup>2</sup>	1408630
59. Right Door Glass <sup>2</sup>	1408629
60. Door Latch	1408628
61. Spacer	1201779
62. Damper Ramp <sup>1</sup>	1301811
63. Slicer/Poker	5005708
64. Long Hinge Plns (4)	1600457
65. SS, SOC 7/16-20 x 1, Cup Pt. Blk	1200334

1. Included in #5008649 upper fireback assembly.
2. Not interchangeable due to a heat-reflective coating on the room side of the panels.

### Shell Enamel Parts - Encore Multi-Fuel Model 2547

Part Name	Classic	Green	Moonlight	Sand	Red	Blue
Top	1308618	2318618	2378618	1328618	2328618	1338618
Left Side	1308623	2318623	2378623	1328623	2328623	1338623
Right Side	1308619	2318619	2378619	1328619	2328619	1338619
Flue Collar	1304280	2314280	2374280	1324280	2324280	1334280
Front	1308635	2318635	2378635	1328635	2328635	1338635
Ashlip	1307406	2317406	2377406	1327406	2327406	1337406
Left Door Subassembly	5008648	30001150	30001345	30001146	30001144	30001148
Left Door Only	1308637	2318637	2378637	1328637	2328637	1338637
Right Door Subassembly	5008647	30001149	30001344	30001145	30001143	30001147
Right Door Only	1308636	2318636	2378636	1328636	2328636	1338636
Single Leg	1307427	2317427	2377427	1327427	2327427	1337427
Back	1308620	2318620	2378620	1328620	2328620	1338620

Door handle <sup>long screw</sup> bolt 1201243