



**FILTER HOUSING
SIDESTREAM INSTALLATION**

**Filter Housing inlet connects to
discharge side of circulation pump.**

**Filter Housing outlet connects to
suction side of circulation pump.**