





## THERMOSTAT HOOK-UP FOR MODELS 5500 ~ 5500XL ~ 6039

The Wall Thermostat Feature works best when burning Premium Quality Pellets or, in the case of the 6039 Multi-Fuel Stove, well cleaned corn with a **maximum moisture level of 12% or less**. Using poor quality fuel may cause the fire to go out when the stove drops down to Heat Setting 1.



**Must remove jumper first**



1. Put female plug fittings on the lead wires to your Low Voltage Thermostat.
2. Remove jumper from terminal posts at bottom center of the Circuit Board.
3. Plug one thermostat lead onto each of the terminal posts on the Circuit Board.
4. Stove will now drop back to Heat Setting 1 when thermostat temperature setting is satisfied.