

## The Acutron 2 control is equipped with 3 different modes:

MANUAL


ON/OFF THERMOSTAT

HIGH/LOW THERMOSTAT

To select or confirm the mode you would like to use do the following:

**1**

Press and hold in the **OFF** button, while you are holding in the off button the following cycle will occur: All the feed rate lights will be solid, then 2 of the feed rate lights will flash together (see the bottom diagram for full cycle).  
note: the starting point of the cycle depends on what mode the control board was in originally.



**2**

To choose the mode you want the board to operate in, simply let go of the **OFF** button when the proper lights flash.  
Below are the modes and light combinations.

- #1 and #2 feed rate lights flash - **ON/OFF THERMOSTAT MODE**
- #3 and #4 feed rate lights flash - **HIGH/LOW THERMOSTAT MODE**
- #1 and #4 feed rate lights flash - **MANUAL MODE**