

TECHNICAL BULLETIN 2011-08 Montpelier Blower Kit

MHSC has improved the Montpelier blower to correct wiring issues and reduce vibration. The Montpelier blower assembly, 30004416, now will come with the snap stat attached to the blower and instructions for proper installation including removal of the old snap stat bracket. See below for the new instructions.



Fan Kit #4416 Installation Instructions for the Montpelier Insert


CAUTION: Unplug power supply. WARNING: Turn unit off and allow to cool completely before beginning installation.



Fig. 2 Remove the power cord bracket and grommet and pull cord through unit.

Screws

Fig. 3 Remove blower assembly.



Installation Instructions

CAUTION: Unplug power supply.

1. Remove the two (2) Phillips head screws holding the cast iron ash lip and lower access doors. Remove the assembly. Figure 1



Fig. 1 Remove the two (2) Phillips head screws.

2. Remove the power cord bracket and pull the cord back through the unit. Figure 2

Screw

- 3. Remove the two or four (2/4) screws holding the blower assembly in place. Pull the complete assembly toward you. Figure 3
- 4. Remove the two (2) screws holding the snap stat bracket in place and remove the complete assembly. Figure 4. A new snap stat and bracket are built into the fan kit.

MHSC 149 Cleveland Drive * Parls, Kentucky 40361 www.mhsc.com

- 5. The new blower assembly has the snap stat attached to the housing. Slide the new assembly into place and install the two or four (2/4) screws. Install the rubber grommet and bracket and run the power cord supplied in the kit out the side of the unit.
- 6. Replace cast iron door assembly. Screws



Fig. 4. Remove snap-stat bracket and discard.

30005539 3/11 Rev 1

Please direct any questions regarding this bulletin toTechnical Service at 1-877-826-0006 or by email at techsupport@mhsc.com

- CHNICAL BULLETIN